

## Verlegeanleitung

# CARONA FLOORS

## LAMINATBODEN

### Vor dem Verlegen beachten...

|                                  |                                   |  |  |  |
|----------------------------------|-----------------------------------|--|--|--|
| <p>1m 3/3'<br/>&lt; 3mm 1/8"</p> | <p>H<sub>2</sub>O ✓<br/>AC/DC</p> | <p>max. 12m 39'3"<br/>max. 8m 26'2"</p> <p>① 10 mm 25/64"<br/>② 20 mm 25/32"</p> | <p>10 mm 25/64"<br/>10 mm 25/64"<br/>C<sub>fl</sub>-s1</p> | <p>PE<br/>0.2 mm 1/64"<br/>1-3 mm 3/64"-13/64"</p> |
|----------------------------------|-----------------------------------|--|--|--|

### Beim Verlegen Schritt für Schritt vorgehen...

|   |                     |                                      |   |  |
|---|---------------------|--------------------------------------|---|--|
| <p>30 mm 1-3/16"<br/>Tape<br/>CA max. 0,3 CM%</p> | <p>10 mm 25/64"</p> |                                      | <p>Clic</p>   | <p>≥ 400 mm ≥ 15-3/4"<br/>12°</p>          |
| <p>12°</p>  | <p>Clic</p>         | <p>10 mm 25/64"<br/>10 mm 25/64"</p> | <p>Ø +20 mm +25/32"<br/>LEIM GLEIT</p>                | <p>10 mm 25/64"<br/>≥ 50 mm ≥ 1-31/32"</p> |
|   |                     | <p>U 50-60%</p>                      | <p>Type »W«<br/>soft / souple<br/>blando / мягкий</p> |  |

### Möglicher Rückbau...



Made in Germany